


## Square Boxes and Accessories


### Box Support Covers

Steel City® Box Support Covers combine a box-to-stud mounting bracket with a device cover in one, easy-to-use product. Designed for use with 4" square boxes, Steel City® Box Support Covers can be used with both steel and wood studs.

- Combines cover and bracket in one component
- Available in one- and two-device versions
- 1/2", 5/8" and 3/4" raised covers
- Speeds installation time
- Needs no far side support
- Can be used with both steel and wood stud
- Can be used without a box as a low voltage device support
- UL and CSA Listed (UL File #E2969, CSA File #LR5043)



52CM13



52CMD17




| CAT. NO.    | RAISED (IN.) | # OF DEVICES | CU. IN. CAPACITY | STD. CTN. |
|-------------|--------------|--------------|------------------|-----------|
| 52CM13      | 1/2          | 1            | 3.0              | 25        |
| 52CM14-5/8  | 5/8          | 1            | 4.0              | 25        |
| 52CM14      | 3/4          | 1            | 5.0              | 25        |
| 52CMD17     | 1/2          | 2            | 6.3              | 25        |
| 52CMD18-5/8 | 5/8          | 2            | 7.3              | 25        |
| 52CMD18     | 3/4          | 2            | 9.0              | 25        |


### 4" Square Surface Covers




RS 4




RS 1



RS 2




RS 3




RS 5

| CAT. NO.  | DEPTH (IN.) | CU. IN. CAPACITY | DIA. HOLE (IN.) | DESCRIPTION                                               | STD. CTN. |
|-----------|-------------|------------------|-----------------|-----------------------------------------------------------|-----------|
| RS 1      | 1/2         | 5.0              | 1 13/32         | For one toggle switch and one single flush receptacle     | 50        |
| RS 2*     | 1/2         | 5.0              | —               | For one toggle switch and one duplex flush receptacle     | 50        |
| RS 3*     | 1/2         | 5.0              | 1 13/32         | For one single and one duplex flush receptacle            | 50        |
| RS 4      | 1/2         | 5.0              | 1 19/32         | For one 4-wire twist-lock single receptacle               | 50        |
| RS 5      | 1/2         | 5.0              | —               | For two toggle switches                                   | 50        |
| RS 8*     | 1/2         | 5.0              | —               | For two duplex, flush receptacles                         | 50        |
| RS 9      | 1/2         | 5.0              | —               | For one toggle switch                                     | 50        |
| RS 10     | 1/2         | 5.0              | 1 13/32         | For two single, flush receptacles                         | 50        |
| RS 11     | 1/2         | 5.0              | 1 13/32         | For one single, flush receptacle                          | 50        |
| RS 12*    | 1/2         | 5.0              | —               | For one duplex, flush receptacle                          | 50        |
| RS 13     | 1/2         | 5.0              | 2 5/32          | For one 30 or 50 amp. dryer or range receptacle           | 50        |
| RS 14     | 1/2         | 5.0              | 2 15/32         | —                                                         | 50        |
| RS 15     | 1/2         | 5.0              | 1 3/4           | For #3330-30A 250 V twist-lock receptacle                 | 50        |
| RS-16-CC  | 1/2         | 5.0              | —               | For one ground fault receptacle                           | 25        |
| RS-17-CC  | 1/2         | 5.0              | —               | For two ground fault receptacles                          | 25        |
| RS-18-CC  | 1/2         | 5.0              | —               | For one ground fault receptacle and one toggle switch     | 25        |
| RS-19-CC* | 1/2         | 5.0              | —               | For one ground fault receptacle and one duplex receptacle | 25        |


Remove portion of G.F.I. receptacle ear to mount receptacle to cover. Screws captivated.




RS 8




RS 9




RS 10




RS 11




RS 12



RS 13




RS 14




RS 15




RS-16-CC



RS-17-CC



RS-18-CC



RS-19-CC