



N95 PARTICULATE RESPIRATOR

DM-400



N95 PARTICULATE RESPIRATOR



N95 PARTICULATE RESPIRATOR // DM-400

- NIOSH approved
- Adjustable nose piece
- Comfortable, secure straps

INSTRUCTIONS FOR USE

1. Hold the respirator in hand with the nose piece at your fingertips, allowing the headbands to hang freely below your hand.
2. Press the respirator firmly against your face with the nose piece on the bridge of your nose.
3. Stretch and position the top band high on the back of the head. Stretch the bottom band over the head and position below your ears.
4. Using both hands, mold nose piece to the shape of your nose.
5. To test fit: a) Cup both hands over the respirator being careful not to disturb position, and b) inhale vigorously. If air leaks around the edges, reposition the straps or adjust strap tension for better fit. Please carefully follow these fitting instructions during each use to achieve proper fit.

NIOSH APPROVED: N95 At least 95% filtration efficiency against solid and liquid aerosols that do not contain oil. Time use restrictions may apply. See insert for approval label.

⚠ WARNING

1. Wearer must read fitting instructions and time use limitations before using.
 2. This respirator is not guaranteed to protect against the risk of contracting a disease or infection.
 3. Before occupational use of this respirator, a written respiratory protection program must be implemented meeting all the local government requirements. In the United States employers must comply with OSHA 29 CFR 1910.134 which includes medical evaluation, training and fit testing.
- 95% efficient protection against non-oil particulates. For non-medical use. This product does not contain latex.

⚠ WARNING: Cancer and reproductive harm. www.P65Warnings.ca.gov.

SPECIFICATIONS

PART #	NIOSH RATING	CARTON CONTAINS
DM-400	N95	20



* Meets requirements of Title 42, Code of Federal Regulations, Part 84 (42 CFR 84)

* Learned By the Food and Drug Administration for use as a Surfaces N95 Respirator, FDA 510 (K): K020477

⚠ CAUTION

SERVICE TIME LIMITATION. Do not use the same respirator for more than 8 hours, continuous or intermittent, in dirty workplaces that could result in high filter loading. Leave contaminated area and remove respirator if breathing becomes difficult, proper fit cannot be obtained or respirator is damaged, soiled or distorted. Do not use the same respirator again once removed. The maximum service time of this respirator is five (5) consecutive calendar days (including days of non-use), beginning from the first day of use.