

### Cleaning Instructions for Electrical Wiring Devices

To properly maintain both the appearance and performance of a Legrand switch, dimmer or outlet, please use only a mild soap or detergent on a damp cloth to clean the device and wall plate. These care instructions should be applied to all electrical wiring devices, including the designer switches and outlets from the adorne® and radiant® Collections.

Approved soaps/detergents: Dawn Ultra Antibacterial Dishwashing Liquid (full concentration); Ajax Ultra Dish Liquid (full concentration); Ivory Dish Soap (full concentration); Gain Ultra Clean Dishwashing Liquid (full concentration); and Ultra Palmolive Antibacterial.

The use of any spray, mister, or aerosol agent is strongly discouraged, as is the use of disinfecting chemicals\* or harsh detergents. These cleaning solutions can damage and degrade the device's plastic casing and are not recommended for use.

\*Please note the following article of the National Electrical Code (NEC) in relation to the use of deteriorating agents on electrical products.

**Article 110.11.** Unless identified for use in the operating environment, no conductors or equipment shall be located in damp or wet locations; where exposed to gases, fumes, vapors, liquids, or other agents that have a deteriorating effect on the conductors or equipment; or where exposed to excessive temperatures.

**FPN No. 1:** See 300.6 for protection against corrosion.

**FPN No. 2:** Some cleaning and lubricating compounds can cause severe deterioration of many plastic materials used for insulating and structural applications in equipment.